



FEDERAL SIGNAL
Safety and Security Systems

Pro LED Beacon

Installation and Maintenance Instructions

25500434

Rev. A3 0123

Printed in U.S.A

© Copyright 2018-2023 Federal Signal Corporation

Limited Warranty

This product is subject to and covered by a limited warranty, a copy of which can be found at www.fedsig.com/SSG-Warranty. A copy of this limited warranty can also be obtained by written request to Federal Signal Corporation, 2645 Federal Signal Drive, University Park, IL 60484, email to info@fedsig.com or call +1 708-534-3400.

This limited warranty is in lieu of all other warranties, express or implied, contractual or statutory, including, but not limited to the warranty of merchantability, warranty of fitness for a particular purpose and any warranty against failure of its essential purpose.



FEDERAL SIGNAL

Safety and Security Systems

2645 Federal Signal Drive
University Park, Illinois 60484

www.fedsig.com

Customer Support

Police/Fire-EMS: 800-264-3578 • +1 708 534-3400

Work Truck: 800-824-0254 • +1 708 534-3400

Technical Support 800-433-9132 • +1 708 534-3400

Contents

Safety Message to Installers and Service Personnel.....	4
Overview of the LED Beacon.....	7
Unpacking the Beacon.....	7
Permanently Mounting the Beacon	8
Wiring the LED Beacon.....	10
Pipe Mounting and Wiring the Beacon.....	12
Configuring the Beacon.....	13
Selecting a Flash Pattern.....	13
Selecting Sync or Alt.....	14
Selecting the Color Order.....	15
Resetting the Beacon to the Default Settings.....	15
Cleaning the Beacon.....	17
Getting Repair Service	18
Ordering Replacement Parts.....	19
Returning a Product to Federal Signal	19

Figures

Figure 1 Permanent-mount beacon (exploded view)	9
Figure 2 Pipe-mount beacon	12

Tables

Table 1 Product specifications.....	7
Table 2 Mounting kit hardware.....	7
Table 3 Wire Connections.....	10
Table 4 Flash Patterns.....	16
Table 5 Replacement Parts	19

Safety Message to Installers and Service Personnel

Safety Message to Installers and Service Personnel

▲ WARNING

People's lives depend on your proper installation and servicing of Federal Signal products. It is important to read and follow all instructions shipped with this product. Listed below are some other important safety instructions and precautions you should follow:

- To properly install or service this equipment, you must have a good understanding of automotive mechanical and electrical procedures and systems, along with proficiency in the installation and service of safety warning equipment. Always refer to the vehicle's service manuals when performing equipment installations on a vehicle.
- To be an effective warning device, this product produces bright light that can be hazardous to your eyesight when viewed at a close range. Do not stare directly into this lighting product at a close range, or permanent damage to your eyesight may occur.
- Do not install the light system in an area that would block, impair, or blind the driver's vision. Ensure that the light system is mounted in a position that is outside of the driver's field of vision so the driver can safely operate the vehicle.
- A light system is a high current system. For the system to function properly, a separate negative (-) connection and positive (+) connection must be made. All negative connections should be connected to the negative battery terminal and a suitable fuse should be installed on the positive battery terminal connection as close to the battery as possible. Ensure that all wires and fuses are rated correctly to handle the device and system amperage requirements.
- Never attempt to install aftermarket equipment that connects to the vehicle wiring without reviewing a vehicle wiring diagram available from the vehicle manufacturer. Ensure that your installation will not affect vehicle operation or mandated

Safety Message to Installers and Service Personnel

safety functions or circuits. Always check the vehicle for proper operation after installation.

- The lighting system components, especially the outer housing, get hot during operation. Disconnect power to the system and allow the system to cool down before handling any components of the system.
- Do not mount a radio antenna within 18 inches (45.7 cm) of the lighting system. Placing the antenna too close to the lighting system could cause the lighting system to malfunction or be damaged by strong radio fields. Mounting the antenna too close to the lighting system may also cause the radio noise emitted from the lighting system to interfere with the reception of the radio transmitter and reduce radio reception.
- Do not attempt to wash any unsealed electrical device while it is connected to its power source.
- DO NOT connect this system to the vehicle battery until ALL other electrical connections are made, mounting of all components is complete, and you have verified that no shorts exist. If the wiring is shorted to the vehicle body or frame, high current conductors can cause hazardous sparks, resulting in electrical fires or flying molten metal.
- DO NOT install equipment or route wiring (or the plug-in cord) in the deployment path of an airbag.
- Before drilling into a vehicle structure, ensure that both sides of the surface are clear of anything that could be damaged. Remove all burrs from drilled holes. To prevent electrical shorts, grommet all drilled holes through which wiring passes. Ensure that the mounting screws do not cause electrical or mechanical damage to the vehicle.
- Because vehicle roof construction and driving conditions vary, do not drive a vehicle with a magnetically mounted warning light installed. The light could fly off the vehicle, causing injury or damage. Repair of damage incurred

Safety Message to Installers and Service Personnel

because of ignoring this warning shall be the sole responsibility of the user.

- Locate the light system controls so the VEHICLE and CONTROLS can be operated safely under all driving conditions.
- After installation, test the light system to ensure that it is operating properly.
- Test all vehicle functions, including horn operation, vehicle safety functions, and vehicle light systems, to ensure proper operation. Ensure that the installation has not affected the vehicle operation or changed any vehicle safety function or circuit.
- Scratched or dull reflectors or lenses will reduce the effectiveness of the lighting system. Avoid heavy pressure and use of caustic or petroleum-based products when cleaning the lighting system.
- Replace any optical components that may have been scratched or crazed during system installation.
- Do not attempt to activate or deactivate the light system controls while driving in a hazardous situation.
- Frequently inspect the light system to ensure that it is operating properly and that it is securely attached to the vehicle.
- After installation and testing are complete, provide a copy of these instructions to instructional staff and all operating personnel.
- File these instructions in a safe place and refer to them when maintaining and/or reinstalling the product. Failure to follow all safety precautions and instructions may result in property damage, serious injury, or death.

Overview of the LED Beacon

The beacon uses an LED light source to provide a reliable signal with 25 selectable flash patterns. The beacon may be flush mounted, pipe mounted, or attached to brackets. The light can operate on a nominal 12 or 24 Vdc power source. Up to four beacons can be synchronized with each other by connecting their sync wires together after individual setup. An optional branch guard is also available.

Table 1 Product specifications

Input Voltage:	11 Vdc to 28 Vdc 12.8 Vdc or 25.6 Vdc (nominal)
Input Current:	4.7 A at 12.8 Vdc pulsed (Tall) 3.3 A at 12.8 Vdc pulsed (Short) 2.3 A at 25.6 Vdc pulsed (Tall) 1.7 A at 25.6 Vdc pulsed (Short)
Flash Rate:	See Table 4 on page 16 for a description of the patterns.
Dimensions:	Height: 5.25 in (13.3 cm) Diameter: 7.25 in (18.4 cm)
Weight:	(Tall): 2.8 lb (1.3 kg) (Short): 2.3 lb (1.0 kg)
Approvals:	SAE J845 Class 1 and CAC Title 13

Unpacking the Beacon

After unpacking the beacon, inspect it for damage that may have occurred in transit. If it has been damaged, file a claim immediately with the carrier, stating the extent of the damage. Carefully check all envelopes, shipping labels, and tags before removing or destroying them. Ensure that the parts listed in Table 2 on page 8 are included in the package.

Table 2 Mounting kit hardware

Qty.	Description
3	Stainless Steel Pan Head Phillips Screw
3	Stainless Steel Nuts
1	Gasket

Permanently Mounting the Beacon

Permanently Mounting the Beacon

The installation requires installer-supplied minimum 18 AWG (1 mm) red and black wire for lengths up to 15 feet (5 m) or minimum 16 AWG (1.5 mm) wire for lengths greater than 15 feet (5 m). A runner wire of minimum 18 AWG (8 feet maximum) should be used if you are synchronizing the flash pattern. Two to five installer-supplied insulated butt connectors and a switch with a current capacity of at least 5 A are also required for the pipe mounting option. An installer-supplied bushing for the wiring is optional. Selecting a flash pattern is optional and should be completed during the installation. For more information, see “Selecting a Flash Pattern” on page 13.

NOTE: Route the wires through a hole drilled into the metal of the mounting location.

To mount the beacon:

1. Scribe the locations of the three mounting holes in the base. (They are evenly spaced 120° apart on a 6.75-inch diameter.)
2. Scribe a hole for the wires and an installer-supplied bushing.


NOTICE

DRILLING PRECAUTIONS: When drilling holes, check the area you are drilling into to ensure that you do not damage vehicle components while drilling. All drilled holes should be deburred, and all sharp edges should be smoothed. All wire routings going through drilled holes should be protected by a grommet or convolute/split loom tubing.

3. Drill a suitably sized hole at the scribed position for the bushing and wire routing hole. Seal the hole with the bushing or RTV. Otherwise, the wires may be routed through the drain notch in the base of the beacon if the cable is trimmed and terminated to two conductors, one for power and the other for ground. Open space must be left for water to drain.

Permanently Mounting the Beacon

Figure 1 Permanent-mount beacon (exploded view)



4. Align the gasket over the drilled holes. Route the wires through the gasket and wire routing hole or through the notch in the base.
5. Secure the base to the mounting surface with the #10 pan head screws and nuts.

Wiring the LED Beacon

Wiring the LED Beacon

NOTICE

REVERSE POLARITY/MISWIRING: To avoid damage to the light, ensure that the input voltage is the same as the voltage rating of the light. Ensure that correct polarity is observed. Also ensure that the unit is properly fused.

Table 3 Wire Connections

Color	Description	Connection Point
Black	Ground	Battery Negative
Red	Mode 1	Switched Positive 12-24 Vdc
White	Mode 2	Switched Positive 12-24 Vdc
Brown	Low Power	Switched Positive 12-24 Vdc
Green	Sync/Program	Another Green Wire/ Positive 12-24 Vdc

To wire the beacon:

1. Determine the required functions and the length of wires needed to access them. A five-conductor cable can be selected for a full-featured installation. For lengths up to 15 feet (5 m), use minimum 18 AWG (1 mm) wire. For lengths over 15 feet, use minimum 16 AWG (1.5 mm) wire.
2. Strip 1/4-inch (5 mm) of insulation from the ends of the installer-supplied wires.
3. Use insulated butt connectors to connect the wires to the power cable of the beacon. Ensure that the connectors are securely crimped and properly insulated.
4. Connect the end of the fuse holder to the positive (+) terminal of the voltage source.
5. Connect the black (–) wire from the beacon to a known good vehicle ground as close to the beacon as practical.

- 6.** Before wiring the beacon, refer to Table 3 on page 10 for the function of each wire.
- 7.** The black wire is ground and is to be connected to a suitable chassis ground if it cannot be taken directly to the negative terminal of the battery.
- 8.** The green wire has a dual function: It is the runner wire that synchronizes multiple beacons or other compatible products, and it also serves as the function/pattern programming wire.
- 9.** The red wire powers the beacon in Mode 1 when connected to a fused, positive voltage.
- 10.** The white wire powers the beacon in Mode 2 when connected to a fused, positive voltage.


NOTE: Mode 2 overrides Mode 1 if Mode 1 is active when Mode 2 is powered up.

- 11.** The brown wire places the beacon into low-power mode when the wire is connected to a fused, positive voltage and either mode is activated.

Pipe Mounting and Wiring the Beacon

The base was designed for the optional installation onto the end of a threaded 1-inch NPT pipe.

Figure 2 Pipe-mount beacon



To pipe mount and wire the beacon:

1. Determine the required functions and the length of wires needed to access them. A five conductor cable may be selected for a full installation. For lengths up to 15 feet (5 m), use minimum 18 AWG (1 mm) wire. For lengths over 15 feet, use minimum 16 AWG (1.5 mm) wire.
2. Strip 1/4-inch (5 mm) of insulation from the ends of the installer-supplied wires.
3. Use insulated butt connectors to connect the wires to the power cable of the beacon. Ensure that the connectors are securely crimped and properly insulated.
4. Connect the end of the fuse holder to the positive (+) terminal of the voltage source.

Selecting a Flash Pattern

5. Route the wires (or five-conductor cable) through the pipe to the location of the installer-supplied switch with a current capacity of at least 5 A).
6. Screw the beacon onto the pipe. Ensure that the wires are not pinched inside the pipe or twisted severely.
7. Connect one terminal of the installer-supplied switch to each required function wire of the beacon.
8. Use minimum 18 AWG (1 mm) wire to connect the remaining switch terminal to one end of the supplied fuse holder and 5 A fuse at 12 Vdc, 3 A fuse at 24 Vdc.
9. Connect the other end of the fuse holder to the positive (+) terminal of the voltage source.
10. Connect the black (–) wire from the beacon to a known good vehicle ground as close to the beacon as practical.

Configuring the Beacon

If the beacon's operating function are to be changed from the default, perform the following steps while the green wire is disconnected from the system.

Selecting a Flash Pattern

⚠ WARNING

LIGHT HAZARD: This product contains a high intensity LED device. To prevent permanent eye damage, DO NOT stare into the light beam at close range.

Selecting a flash pattern from the beacon's internal library of flash patterns is optional. It should be done during installation. For the flash patterns, see Table 4 on page 16

To select a flash pattern:

1. Select the Mode 1 (red wire) or Mode 2 (white wire)
2. Apply power (+12-24 Vdc) to that wire.

Selecting Sync or Alt

3. Select a flash pattern by tapping the green wire to + 12-24 Vdc until desired pattern is reached.

NOTE: When tapping the green wire to change patterns, do not hold power for longer than 1 second, or other features of the beacon will change.

Selecting Sync or Alt

⚠ WARNING

When setting up devices to be synchronized, they must never be operated without a good ground connection. If a poor ground connection exists, the unit will operate erratically, and will void the warranty. Routinely inspect all connections to ensure they are secure.

The beacon can synchronize with other beacons. It will either flash with or alternate the timing of the flashes with other beacons. Select this feature separately for Mode 1 or Mode 2.

To synchronize your selected flash pattern:

1. Activate the mode (1 or 2) for which the synchronize feature is to be set.
2. Connect and hold the green wire to the positive voltage source until the beacon pulses twice, and then release it. The beacon switches from its initial setting to its opposite. Flash with becomes Alternate, or Alternate becomes Flash with.
3. To synchronize, after setup, connect the green wires together.

For this feature to operate, all green wires should be permanently connected together after all of the beacons in the system are configured.

Resetting the Beacon to the Default Settings

Selecting Single or Dual Color (if equipped)

The beacon can be made to either flash a single color or two colors. This is done separately for Mode 1 or 2.

To select single or dual color:

1. Activate the mode for which this color feature is to be set.
2. Connect and hold the green wire to power until the beacon pulses three times, and then release it.
3. The beacon switches from its initial setting to its opposite. Single Color becomes Dual Color, or Dual Color becomes Single Color.

Selecting the Color Order

You can set the order in which a beacon flashes. The order is selected separately for Mode 1 or Mode 2.

To select the color order:

1. Activate the mode for which this color feature is to be set.
2. Hold the green wire to the positive voltage source until the beacon pulses four times, and then release the wire. The beacon switches color from the initial setting to its opposite. For example: A dual color, amber-red beacon set to flash amber and then red will change to flashing red and then amber. A dual color, amber-red beacon set to the single color red will become amber.

Resetting the Beacon to the Default Settings

To reset the beacon mode to the default settings, apply power to the green wire while either Mode 1 or Mode 2 is powered. Hold the wire to the power source until the beacon pulses six times and then remove power. Repeat for each Mode you want to reset.

NOTE: No change occurs if you remove power from the green wire after five pulses and before the sixth pulse finishes.

Wiring the LED Beacon

Table 4 Flash Patterns

Pattern No.	Description	Flash Rate (FPM)
1 *	Double Quad	60
2	Chopped Double	60
3	Double Pulse	80
4	Pulsing Quad	60
5	Triple FedPulse	60
6	Rotating	116
7	Breathing	60
8	Random Full, All Patterns	Various
9	Random, Select Patterns #11-25	Various
10**	Steady for 3	N/A
11	Single Flash, Slow	75
12	Single Flash	120
13	Double Flash	80
14	Double Flash Fast	120
15	Triple Flash	80
16	Triple Flash Fast	120
17	Quad Flash Slow	60
18	Quad Flash	75
19	Quad Flash Fast	95
20	Quad FedPulse	75
21	5x Flash	75
22	7x Flash	80
23	Single Flash 120 FPM/Quad 60 FPM	120/60
24	Decelerating	60
25	Accelerating	60

**Pattern 1 is the default for Mode 1*

***Pattern 10 is the default for Mode 2*

Cleaning the Beacon

⚠ WARNING

CRAZING/CRACKING *Crazing (fine cracks) of lenses causes reduced effectiveness of the light. Do not use cleaning agents (which causes crazing) such as strong detergents, solvents, or petroleum products. If crazing of the lenses does occur, the reliability of light for emergency signaling purposes may be reduced until the lenses are replaced.*

NOTICE

CLEANING the POLYCARBONATE LENSES: *To extend the life of this device, periodic cleaning is necessary. Clean the lens with a mild, non-abrasive, neutral-pH cleaning agent and a soft, clean cloth. Rinse the device thoroughly to ensure that no cleaning agent residue remains. To avoid water spots, dry the device with a soft clean cloth. Failure to follow this precaution can cause crazing or cracking of the lens/dome and voids the warranty claims for the light.*

Frequently inspect the beacon to ensure that it is securely attached to the vehicle and operates properly. Clean the beacon with a mild soap and a soft rag.

Getting Repair Service

Getting Repair Service

The Federal Signal factory provides technical assistance with any problems that cannot be handled locally. Any product returned to Federal Signal for service, inspection, or repair must be accompanied by a Return Material Authorization (RMA). Obtain a RMA from a local Distributor or Manufacturer's Representative. Provide a brief explanation of the service requested, or the nature of the malfunction.

Address all communications and shipments to the following:

Federal Signal Corporation
Service Department
2645 Federal Signal Dr.
University Park, IL 60484-3167

Ordering Replacement Parts

To order replacement parts, call Customer Support at 1-800-264-3578, 7 a.m. to 5 p.m., Monday through Friday (CT) or contact your nearest distributor.

Table 5 Replacement Parts

Description	Part No.
Dome, Tall, Amber	862702014-02
Dome, Short, Amber	862702014-02-S
Dome, Tall, Blue	862702014-03
Dome, Short, Blue	862702014-03-S
Dome, Tall, Red	862702014-04
Dome, Short, Red	862702014-04-S
Dome, Tall, Clear	862702014-05
Dome, Short, Clear	862702014-05-S
Dome, Tall, Green	862702014-06
Dome, Short, Green	862702014-06-S
O-Ring, Lens	862702247
Pad, Mounting	862702265

Returning a Product to Federal Signal

All products returned must be accompanied with a Returned Merchandise Authorization (RMA) number. To obtain an RMA number, call 1-800-433-9132.



FEDERAL SIGNAL
Safety and Security Systems

2645 Federal Signal Drive
University Park, Illinois 60484

www.fedsig.com

Customer Support

Police/Fire-EMS:

Work Truck:

Technical Support

800-264-3578 • +1 708 534-3400

800-824-0254 • +1 708 534-3400

800-433-9132 • +1 708 534-3400