



LIGHTING PRODUCTS

FEDERAL SIGNAL CORPORATION
2645 Federal Signal Dr., University Park, IL 60484-3167
TEL 800.433.9132 FAX 800.343.9706
www.fedsig.com

TRIPOD TELESCOPIC POLE

INSTALLATION INSTRUCTIONS

Refer to the General Lighting manual or lamphead specific sheets for safety and maintenance.

Install Quick Release Bracket Set for Tripod

The quick release mounting bracket set hold a tripod securely on the vehicle. The mounting bracket set consists of a lower base into which the bottom of the tripod legs rest, and an upper locking bracket, which has a quick release knob on the right side.

1. Place the tripod in position to check for fit.

Note: The mounting brackets are aligned left and not centered on each other.

2. Mark the mounting hole locations.
 - a. Align the left sides of the brackets and the left side mounting holes for the tripod to fit correctly.
 - b. The upper bracket can only be mounted with the pull knob to the right side.
 - c. Use the brackets as templates.

Helpful Hint: Mount the bottom bracket first. Attach the quick release bracket to the hole on the upper slide casting of the tripod. Rest the tripod legs in the base, and push the upper bracket in position flush to the mounting surface. Mark the top bracket hole locations.

3. Drill the mounting holes. The mounting brackets are predrilled for 1/4-20 hardware.

Note: Tripods with some lampheads require that the 7/8" spacers be installed between the mounting surface and the brackets so the back of the lamphead clears the mounting surface.

4. Install the mounting brackets (and spacers when required).



Quick Release Bracket Set
(Shown with lamphead spacers.)



Dual Quick Release Bracket
(The lock can be released from either side.)

**Tripod
Telescopic Pole**



Install Tripod Quick Release Bracket Set

