Installation Instructions for the CNSM-FRD18ND Mounting Kit in the Ford® F-150

25500523A REV A 0219

Safety Message to Installers of Warning Light Equipment

A WARNING

People's lives depend on your proper installation and servicing of Federal Signal products. It is important to read and follow all instructions shipped with this product and the original product. In addition, listed below are some other important safety instructions and precautions you should follow:

- To properly install the lighting system, you must have a good understanding of automotive systems, along with proficiency in the installation and use of safety warning equipment.
- Do not install equipment or route wiring in the deployment path of an airbag.
- If a vehicle seat is temporarily removed, verify with the vehicle manufacturer if the seat needs to be recalibrated for proper airbag deployment.
- Do not stare into the lights at close range or permanent damage to your eyesight may occur,
- When drilling into a vehicle structure, be sure that both sides of the surface are clear of anything that could be damaged.
- Refer to the instructions packed with related products for additional precautions and information.
- You should frequently inspect the light system to ensure that it is operating properly and that it is securely attached to the vehicle.
- File these instructions in a safe place and refer to them when maintaining and/or reinstalling the product.
- Do not stare directly into the lights at a close range or permanent damage to your eyesight may occur.

Failure to follow all safety precautions and instructions may result in property damage, serious injury, or death.

Product Overview

This publication has instructions for using the CNSM-FRD18ND Mounting Kit to mount the 4 head CN SignalMasterTM in the grille of the Ford[®] F-150.

IMPORTANT: This kit is designed for vehicles with the grille shown in Figure 1.



Figure 1 F-150 grille

NOTE: For electrical installation instructions, refer to the Installation and Maintenance Instructions packed with the lighthead.

Unpacking the Kit

After unpacking the kit, inspect it for damage that may have occurred in transit. If it has been damaged, do not attempt to install or operate it. File a claim immediately with the carrier, stating the extent of damage. Carefully check all envelopes, shipping labels, and tags before removing or destroying them. Ensure that the parts in the Kit Contents List are included in the package. If you are missing any parts, contact Customer Support at 1-800-264-3578, 7 a.m. to 5 p.m., Monday through Friday (CT).

Part Number Qty. **Description** 1 BRKT, DS, CNSM, GRILLE, F-150 865202839A 1 BRKT, PS, CNSM, GRILLE, F-150 865202842A 2 BRKT ASSY, RETAINER, CNSM, GRILLE, F-150 865202843A 4 NUT, EL STOP, THIN, 1/4-20, SS 7058055A 4 WASH, FLT, SS, .266X11/16X.063 7072A024 SCR,#10 TYP B,PAN TORX, STL BLK ZINC 7011246A-06

Table 1 Kit contents

Mounting the 4 head CN SignalMaster

IMPORTANT: Plan all cable routing before the installation.

A WARNING

AIRBAG DEPLOYMENT—Do not install equipment or route wiring in the deployment path of an airbag. Failure to observe this warning will reduce the effectiveness of the airbag or potentially dislodge the equipment, causing serious injury or death.


NOTICE

DRILLING PRECAUTIONS—Check the area into which you are drilling to be sure you do not damage vehicle components. All drilled holes should be deburred and all sharp edges should be smoothed. All wire routings going through drilled holes should be protected by a grommet or convolute/split loom tubing.

To mount the lightbar:

- 1. Remove the grille/shutter assembly from the vehicle according to the vehicle manufacturer's instructions. Place it on flat workbench so that the front and rear of the grille is accessible.
- 2. If not already open, manually rotate the shutter assembly by hand so that it is in the open position.
- **3.** Use Figure 2 to distinguish between the driver and passenger side brackets.

Figure 2 Passenger side VS driver side bracket comparison




4. Place the driver side bracket on the grille in the location shown in Figure 3. It is necessary to insert the bracket through the center opening in the grille to allow the bracket to fit.



Figure 3 Completed installation

- **5.** Secure the bracket to the grille using a retainer bracket assembly, 2 washers, and 2 elastic stop nuts. Do not tighten hardware.
- **6.** Repeat steps 4 and 5 for the passenger side.

7. Insert the CN SignalMaster into the grille from the rear. It will be necessary to deflect the shutters slightly to allow it to fit. Secure the CN SignalMaster to the two brackets using the 8 supplied #10 screws. See Figure 4.





- **8.** Adjust the CN SignalMaster so that it is in the desired position and tighten all hardware. Do not overtighten.
- **9.** Complete the wiring in a way that the wires exiting the CN SignalMaster do not interfere with the shutter system. If this is not achievable, notch out the shutter in the location of interference. See Figure 5 for exploded view.

IMPORTANT: Frequently inspect the lightbar to ensure that all fasteners and brackets are tight.




Figure 5 Final assembly exploded view

Ford® F-150

6

Getting Technical Support

For technical support, please contact:

Federal Signal Corporation Service Department Phone: 1-800-433-9132

Phone: 1-800-433-9132 Fax: 1-800-343-9706

Email: empserviceinfo@fedsig.com

Getting Repair Service

The Federal Signal factory provides technical assistance with any problems that cannot be handled locally. Any units returned to Federal Signal for service, inspection, or repair must be accompanied by a Return Material Authorization (RMA). Obtain a RMA from a local Distributor or Manufacturer's Representative. Provide a brief explanation of the service requested, or the nature of the malfunction.

\Address all communications and shipments to the following:

Federal Signal Corporation Service Department 2645 Federal Signal Dr. University Park, IL 60484-3167

Ordering Replacement Parts

To order replacement parts, call Customer Support at 1-800-264-3578, 7 a.m. to 5 p.m., Monday through Friday (CT) or contact your nearest distributor.



2645 Federal Signal Drive University Park, Illinois 60484-3167

www.fedsig.com

Customer Support

Police/Fire-EMS: 800-264-3578 • +1 708 534-3400 Work Truck: 800-824-0254 • +1 708 534-3400 Technical Support: 800-433-9132 • +1 708 534-3400

© Copyright 2019 Federal Signal Corporation

SignalMaster is a trademark of Federal Signal Corp. Ford is a registered trademark of Ford Motor Company.