

料號：86-FSW111-010

材質：100P雙銅紙 / 單面四色印刷

尺寸：(W)110 x (H)158mm

日期：20170704(版本1.0)

編號：GD106072503

摺法：無



FEDERAL SIGNAL 8-inch Round Patient Light

2645 Federal Signal Drive
University Park, IL 60484-3167
22500418 Rev. A0 0717

⚠ WARNING

To properly install this light, you must have a good understanding of automotive electrical procedures and systems, along with proficiency in the installation and use of safety warning equipment.

WIRING

Single Color Edition

To Vehicle -Ground.....**BLACK**
To +12VDC (fuse rating @2A) for Bright Mode in Color 1.....**RED**
To +12VDC (fuse rating @2A) for Dim Mode in Color 1.....**WHITE**

Dual Color Edition

To Vehicle -Ground.....**BLACK**
To +12VDC (fuse rating @2A) for Bright Mode in Color 1.....**RED**
To +12VDC (fuse rating @2A) for Dim Mode in Color 1.....**WHITE**
To +12VDC (fuse rating @2A) for Color 2.....**YELLOW**

MODES OF OPERATION

Operating in Color 1 Bright Mode

With the black wire connected to vehicle ground, connect the red wire to +12VDC to illuminate the light in Bright Mode in Color 1.

Operating in Color 1 Dim Mode

With the black wire connected to vehicle ground, connect the white wire to +12VDC to illuminate the light in Dim Mode in Color 1.

NOTE: Bright Mode has priority over Dim Mode.

Operating in Color 2 (for Dual Color Edition Only)

With the black wire connected to vehicle ground, connect the yellow wire to +12VDC to illuminate the light in Color 2.

NOTE: When Color 1 and Color 2 are activated simultaneously, both colors will operate in Dim Mode.

INSTALLATION

1. Create a Ø7.00-inch cut-out on the selected mounting surface.
2. Make all wiring connections.
3. Mount light using supplied hardware.
4. Test for proper operation.

Customer Support: 1-800-264-3578

Service Department: 1-800-433-9132

www.fedsig.com: 1-708-534-3400