

Call Point Replacement Faceplate Labels and Duty Plate Option Installation Instructions

Safety Messages to Installers

It is important to follow all instructions shipped with this product. This Call Point station and its options are to be installed by a trained electrician who is thoroughly familiar with and will follow all applicable national and local codes in the country of use. This Call Point station should be considered a part of the warning system and not the entire warning system. The selection of the mounting location for the Call Point station, its controls and the routing of the wiring are to be accomplished under the direction of the facilities engineer and the safety engineer. In addition, listed below are some other important safety instructions and precautions you should follow:

- Read and understand all instructions before installing and operating this equipment.
- To avoid electrical shock hazards, do not connect wires when power is applied. Failure to observe this warning may lead to serious injury or death.
- Never alter the unit in any manner. Safety in hazardous locations may be endangered if additional openings or other alterations are made in units specifically designed for use in these locations.
- Do not connect this station to the system or modify it when power is on.
- After installation, ensure that all threaded joints are properly tightened.
- Keep the unit tightly closed when in operation.
- After installation, test the station and the system to ensure that it is operating properly with the option installed
- After testing is complete, provide a copy of this instruction sheet to all personnel.
- Establish a procedure to routinely check the station and system for proper activation and operation.

Failure to follow all safety precautions and instructions may result in property damage, serious injury, or death.

Replacing the Station's existing Faceplate Label

⚠ WARNING

The polyester (K71400935A-xx) and stainless steel (K71400976A-xx) faceplate labels are only to be used on non-EN54-11 Federal Signal Manual Call Point stations. The K71400701A is the ONLY faceplate label that may be applied to EN54-11 stations, any other one of these labels being applied over, or replacing the factory installed EN54-11 flaming building label will void its certification.

The polyester (K71400935A-xx) and stainless steel (K71400976A-xx) faceplate labels within this kit are provided as a service/accessory part for existing Federal Signal Call Points stations in need of a replacement faceplate label. The polyester labels have either white or black text over a clear background with "FIRE", "EVAC", "GAS ALARM", "BIOHAZARD ALARM", "LOCKDOWN", "EMERGENCY", "SHUTDOWN", or an Evac logo, all provided on one sheet for multiple applications. The stainless steel labels have black text with "FIRE", "EVAC", "GAS ALARM" or "BIOHAZARD ALARM" provided as individual labels. Remove the existing label and be certain that the application area is free from any dirt, residue from previous label, smudges or oil prior to application. Residue removal cleaners must be applied locally to the area of the new label's application. All labels have a peel off paper liner exposing a pressure sensitive adhesive backing. Initial placement is critical as the adhesive is aggressive once it touches the station's faceplate designated label area.



